


How to DISABLE a FastCAM® Software license

1. Hold down the **SHIFT** key and then run the program you wish to **DISABLE**. Making sure to keep the **SHIFT** key held down, until a window appears.
2. When this screen appears, click the “**DISABLE Current License**” button.



3. Then note down the **SERIAL** number and the **DISABLE LEVEL** License number (between the brackets) and forward these to FastCAM.

